


1 SWITCHING ON/OFF

Press and hold the red button for 2 seconds to turn on.

Press and hold for 3 seconds to turn off.


To change the volume level between 1 to 4, press and release the red button.



4 SWITCHING ON/OFF THE NIGHT LIGHT FUNCTION

When the base senses darkness for more than 30 seconds it will automatically switch into night mode.


To turn the night light system off hold the yellow button for 3 seconds.



2 SETTING THE MESSAGE TIMER

The green button is to increase or decrease the message timer intervals, from 20, 40 or 60 minutes.


The reminder messages can also be turned off.



5 LISTEN AND RECORD PRE-SET AND PERSONALISED MESSAGES

The blue button is to listen to the 3 pre-set reminder messages and to record personalised reminder messages.


Press and release the blue button and the system will talk you through the settings.



3 SETTING THE REMINDER LIGHT TIMER

The yellow button is to increase or decrease the reminder light timer intervals, from 20, 40 or 60 minutes.

The warning lights can also be turned off.



6 RE-SETTING THE DEVICE TO FACTORY SETTING

To delete all personalised messages and return to default messages. Press and hold both the blue and green buttons together for 3 seconds.